




FC-35 GRIP


Connecting the grip to the Thrustmaster base



1. Disconnect the Thrustmaster base from the PC



2. Connect and install the FC-35 grip onto the Thrustmaster base



3. Set the FC-35 grip to Thrustmaster compatibility mode

3.1 Press the button

3.2 While holding the button, connect the Thrustmaster base to your PC

3.3 After connecting the Thrustmaster base to the PC, hold the button for 2 seconds



LET'S FLY!